

# HYDROPHONE SELECTION

Active hydrophone in use is displayed in the vessel window.

Vessel window



Active hydrophone



Point in the Vessel window and press

Hydrophone selection



Select Manual / Auto and/or hydrophone set #

In Manual, also select hydrophone